

Genesis Gear Remote Switch

Genesis Gear Remote Switch is a device that will find use in the hands of many photographers. It is designed to remotely trigger the shutter on your camera. Whether you're shooting astrophotography, landscape photography, or taking self-portraits, the shutter release cable will play a very important role. When shooting with a long exposure time, any movement of the camera will be registered, causing blurriness and motion in the photo. The remote connection of the shutter release cable will prevent any undesirable effects. This product is available in different models.

Available variants:

- Genesis Gear Remote Switch for Canon RS-60E3
- Genesis Gear Remote Switch for Cano RS-80N3
- Genesis Gear Remote Switch for Nikon MC-30
- Genesis Gear Remote Switch for Nikon MC-DC2
- Genesis Gear Remote Switch for Sony RM-VPR1

Warrianty:

- 2 years



EAN code:

Genesis Gear Remote Switch for Canon RS-60E3	5901698723330
Genesis Gear Remote Switch for Cano RS-80N3	5901698723347
Genesis Gear Remote Switch for Nikon MC-30	5901698723354
Genesis Gear Remote Switch for Nikon MC-DC2	5901698723361
Genesis Gear Remote Switch for Sony RM-VPR1	5901698723378