

GENESIS GEAR URSASLIM BAG

Adjustable internal partitions

Modular, easy and convenient moving equipment.

Laptop compartment up to 13"

Laptop securing pocket in transport.

Tablet compartment

Pocket dedicated to the tablet. (22x21cm)

Quick access

Fast access to equipment through the top lock.

Outer pocket on the flap

Additional pocket for you accesories.

Attaching to the trolley

Special strap fastening to the bags with wheels.

Outer hip pocket

Additional pocket for important things that you always want to carry with you.

Two side pockets of free access

Side pockets allow you to store additional items such as a bottle of water.

Magnetic closure of the flap

Magnetic clasp makes our equipment is always safe.

Adjustable strap

Adjustable strap lenght and metal buckles that ensure high durability.

Watertight zippers

Watertight zips guarantee protection of the equipment against rain.

Hydrophobic material

High abrasion resistance ensures durability for years.

Removable compartment insert

Taking out the insert will make our bag become a universal for everyday tasks.

Cabin luggage

Dimensions of the bag allow you to take it to the aircraft as hand luggage – due to the changing rules of individual companies, please check the specific airlines before journey.



External dimensions:	30 x 40 x 12 cm
Interior dimensions:	27 x 37 x 11 cm
Weight:	1071g
Warranty:	24 months
Price:	34,50€



EAN: 5901698717797



- A new, slim version of urban photography bags from Genesis Gear brand. Ideal for the owners of mirrorless cameras and small cameras, it is suitable for transporting one body, an additional lens and other accessories. Perfect for street photography and reportage. It will fit the tablet and laptop up to 13 inches. The bag is equipped with a top zipper that facilitates quick access to our equipment, and a magnetic anti-theft lock. Inside the bag there is a rigid chamber equipped with a system of adjustable partitions. They are relatively thick to absorb shocks and prevent damage to the equipment as it moves inside the bag.

SAFETY

The external material that we used is hydrophobic, while zip fasteners are sealed. Such solutions help to protect the interior of the bag during adverse conditions, because water does not penetrate the bag. When choosing extreme weather conditions an additional, optional rain cover should be used.

QUICK ACCESS

All of us – photographers, met with a situation when we took literally seconds to take a picture. In this case, quick access to the equipment is almost priceless, and in this bag it is possible through a hole with a zip, located in its upper part.

TAILORED TO YOU

The bag is meant to be used by photographers, but nothing prevents you from adapting it to everyday use. All you have to do is take out the main compartment.

In package: bag, shoulder belt, pull-out main compartment .



URSA SLIM
TAILORED TO YOU

